

## SacCityCorvette's LS Bypass Check Valve Removal & Delete Installation Instructions

You will need a 13mm, or 1/2" hex socket or Hex (Allen) wrench to remove the threaded oil filter adapter and a 2" or 3" (longer the better) 3/8"-18 bolt.

After removing the filter adapter screw the 3/8-16 bolt in the check valve using a drill, impact or ratchet and "force" thread it in to the Bypass, rocked it side to side, and it will pop out. One other way is to grab the bolt with ViseGrips and then grab that ViseGrip with with another one so you have a "L" shape that you can use a hammer and pound straight down on it like a slide hammer.

Once you have the Bypass out, thoroughly clean area with brake cleaner . Then lube O ring on you new Bypass Delete and install it. Reinstall the filter adapter and a new filter and your finished.

Thank you for your Business and please contact us with any questions or comments!

[Sales@saccitycorvette.com](mailto:Sales@saccitycorvette.com)

916 968-4451