

SacCityCorvette

C5 Big 3 Side Post Terminal Instructions

Please watch the installation Video on our website before you start!

Also read these instructions!

www.saccitycorvette.com/Big-3.html

Or go to this YouTube link, just type it into your browser.

<https://youtu.be/dDhp1QCsQkk>

This video is of the early version Big 3, we have made a few upgrades to our latest Big 3's that you have received, but the instructions in the video are basically the same.

Upgrade changes from video Big3

Now the Big 3 has the fuse box cable (Term#3) mounted in the Big 3 Fuse block.

Protective Corrugated sleeve for a more factory look.

We are using a higher strand more flexible wire.

Star washers on terminals and head ground bolt no longer needed.

Numbered Terminals for easy identification and location. (follow instructions below)

CAUTION- The first step when installing your Big 3 kit is to disconnect the Negative (Ground) from the battery! The Negative cable is the very LAST thing you will reconnect after everything has been installed!

- 1 Disconnect Negative & Positive cables from battery. Disconnect the Negative cable first.
- 2 Remove the factory terminals from the cables. They will be replaced with the ones in the kit.
- 3 Remove cover from the under-hood Fuse Box.
- 4 Mount Big 3 Fuse Block as shown in video.

There are numbers on the cable terminals that correspond with the list below.

Term # 1 – Attach to positive stud on Alternator. (See Video)

Term # 2 – Attach to battery Positive brass stud supplied in kit. (See Video)

Term # 3 – Slip on to fuse box stud and use supplied nut and tighten down. Do not remove factory nut. (See Video)

Term # 5 – Attach to Negative battery brass stud supplied in kit. (See Video) The Negative Battery terms will be the last thing you install!

Term # 6 - Attach to ground stud on frame below Battery using supplied nut. Do not remove factory nut! (See Video)

Term # 7 – Attach to ground stud on frame below Coolant reservoir using supplied nut. Do not remove factory nut! (See Video)

Term # 8 – Attach to head using supplied bolt. (See Video)

If you have any questions call/Text 916 968-4451 or email us at sales@saccitycorvette.com

REV.7/10/2019







