

C5 Corvette Hood Seal

Clean area thoroughly and make sure it is dry.

Layout and cut to length. The tape faces forward and the flat side faces down.

Practice fitting before peeling tape.

When you are ready to install, peel a section at a time and place exactly where it should go. **Do not stretch seal as you are installing it.** The tape is very sticky and unforgiving if you stick in the wrong place.

The little creases in rubber seal will disappear in a few days.
See website for colored version of these instructions.

Thanks you for your purchase!

If you have any question Email, Text or Call SacCityCorvette .

Sales@saccitycorvette.com

www.saccitycorvette.com

916 968-4451

